



Top doesn't have pre-drilled holes. -Use grey marks underneath the cover to align the base on the top before install the screws









