ASSEMBLY INSTRUCTION FOR MODEL: Van Sideboard Bolts M6x25 4 Handles 2 4 ★ REMARK:There is a tip restraint kit Key K4 3 1 provided on the back of this product please read the direction thoroughly and install immediately Tipping Hardware 2 Step 1 (2)(3) 1 Step 2 3 Figure 1 **Tipping Hardware**