

ASSEMBLY INSTRUCTIONS

ITEM NO: IHTN-010

Description: AVA LARGE CHANDELIER-ANTIQUE IRON



These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

We strongly suggest that all hard wired fixtures be installed by a professional electrician.

Parts Included:

1. Main Body
2. Mounting Plate
3. Canopy
4. Loop
5. Socket Cluster
6. Glass (10 Pcs)
7. Socket Assembly
8. Metal Pipe(2pcs-12" & 1 pc-6")

Hardware Enclosed:

1. (2) Mounting Screws
2. (2) Plastic Wire Connectors
3. (1) Green ground screw
4. (1) Allen Key

To Install You Will Need:

1. 2 people recommended (Not Provided)
2. Phillips Screwdriver (Not Provided)
3. Electrical tape (Not Provided)
4. Wire cutters (Not Provided)

To Assemble:

1. Carefully remove the protective covering on the iron frame using scissors.
2. We recommend two people install this chandelier. At this step, one person is needed to hold the chandelier while the other screws the cluster to the body.
3. Hold the main body then tighten the pipes (2pcs-12" & 01 pc-6") to the main frame & pull the wire through canopy.
4. Shut off the main electrical supply from the main fuse box/circuit breaker.
5. Gently pull wiring down from ceiling junction box and allow to hang.
6. Remove mounting plate from the canopy by unscrewing the collar.
7. Carefully inspect the chandelier's fixture wires. The neutral fixture wire has very fine ridges molded into its plastic covering. The hot fixture wire has a smooth covering. The bare copper wire is the ground wire.
8. Wrap ground wire of lamp assembly and ground wire of junction box together and fasten together with a wire nut and wrap the connection with electrical tape.
9. Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
10. Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape.
 - a. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
11. Gently tuck the wire connections neatly into the ceiling junction box.
12. Place the mounting plate over the center of the ceiling junction box.
13. Align holes in mounting plate with holes in junction box and attach with two mounting bolts. Secure bolts with a Phillips head screwdriver.
14. Push canopy up over the mounting plate until it is flush with the ceiling.
15. Push collar through hole in canopy and thread onto nipple on the mounting plate. Secure by turning collar clockwise until canopy is flush with the ceiling.
16. Then remove the iron bush & put the glass & then tighten the bush.
17. Insert 10Type B 25W bulbs into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
18. Restore power to junction box and test fixture. **DO NOT EXCEED SPECIFIED WATTAGE OF PENDANT.**

CARE INSTRUCTIONS

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.