

## **ASSEMBLY INSTRUCTION**

## Langham Sectional


## Universal assembly of the sectionals



The prong and the connector must be aligned well.



## How to disconnect



Lift up the right sectional and pull it out .

