



# **INNES FLOOR LAMP**

#### PARTS ENCLOSED:

ITEN	1 DESCRIPTION	QTY.
(A)	Floor Lamp Base	1
(B)	Harp Holder	1
(C)	Socket	1
(D)	Bulb	1
(E)	Harp	1
(F)	Fabric Shade	1
(G)	Finial	1







#### **IMPORTANT SAFETY INSTRUCTIONS:**

- 1. This fixture has been rated for 1 x 9 Watt SBLED maximum Type A standard bulb.
- 2. To avoid the risk of fire, do not exceed the recommended wattage.
- 3. The manufacturer and distributor accept no liability for incorrect installation.
- 4. For indoor use only.
- 5. Keep away from children.

#### **WARNINGS:**

- 1. Turn off / unplug and allow to cool before replacing bulb (lamp).
- 2. Do not touch bulb or look directly at lighted lamp.
- 3. Keep flammable materials away from light bulb.

### TO ASSEMBLE:

- 1. Carefully unpack the floor lamp. Do not discard any material till assembly is complete.
- 2. Install one Type A bulb 9 Watt SBLED (D) Maximum into the Socket (C).
- 3. Install the Harp (E) to the Lamp Base (A) into the Harp Holder (B).
- 4. Install the Fabric Shade (F) to the Harp (E) and tighten with Finial (G).

## CARE INSTRUCTIONS:

To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners.