

ASSEMBLY INSTRUCTION FOR
SOTO CONSOLE TABLE

A		Screwdrivers (Not included)	1 PC
---	--	--------------------------------	------





