


ASSEMBLY INSTRUCTIONS


WALLER SOFA LOUNGE - CUSHION COVER

1


BACK CUSHION COVER



FLIP THE SEAT
CUSHION COVER
UPSIDE DOWN





SEAT CUSHION COVER




2

BACK CUSHION





SEAT CUSHION


5




4




FLIP THE SEAT
CUSHION COVER
UPSIDE DOWN



UNZIP COVER
THEN
INSERT
CUSHIONS
INTO COVERS



3



FABRICS MAINTENANCE



Direction of maintenance :

1. Machine wash in luke warm water (up to 40°C, 100°F) at a gentle setting (reduced agitation).
2. A mild bleach agent can be used for cleaning, Avoid concentrated bleach application.
3. Ironing (Low 110 ° C, 230 ° F).
4. Do not dryclean.
5. Tumble dry, low permanent press.