



THE 'IT TAKES AN HOUR SIDEBORD' V2

ASSEMBLY INSTRUCTIONS

* **REMARK:** There is a tip restraint kit provided on the back of this product please read the direction thoroughly and install immediately

HARDWARE LIST

1		[2] Anti-tip Kit Set
---	---	----------------------



STEP: 1

ADJUST FLOOR LEVELERS




Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

ADJUST FLOOR LEVELERS

Check for Stability – Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

Locate the Levelers – These are small adjustable feet found at the bottom corners of your furniture.



Adjust as Needed – Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.




THE 'IT TAKES AN HOUR SIDEBORD' V2

ASSEMBLY INSTRUCTIONS



STEP: 2



NOTE:
Refer the instructions on the anti-tip kit bag.



STEP: 3



THE 'IT TAKES AN HOUR SIDEBORD' V2

ASSEMBLY INSTRUCTIONS

! WARNING

For use with televisions weighing 175 lbs / 80 (Kg) or less.

Attention : this unit is not rated for use with a CRT type television

! WARNING

Death or serious injury may occur when children climb on audio and/or video equipment furniture.

A remote control or toys placed on the furnishing may encourage a child to climb on the furnishing and as a result the furnishing may tip over on to the child.

! WARNING

Relocating audio and/or video equipment to furniture not specifically designed to support audio and/or video equipment may result in death or serious injury due to the furnishing collapsing or over turning onto a child.

All other support shelves should not be loaded more than 25 lbs.

DO NOT EXCEED RECOMMENDED LOAD. Use with heavier televisions may result in instability causing tip over resulting In death or serious injury.

Please use caution when using electrical equipment. Improper use could result in the risk of fire, electric shock or injury to persons associated with the use of this unit during operation, user-maintenance, loading, storage, and, as applicable, electrical issues including grounding or double-insulation

Electronic components generate heat that may cause damage to the equipment. Please refer to the manufacturer's owner's manual for space and ventilations requirements.

Do not allow children under 16 years to move cart.

