


238692-003 - MCCARTHY PENDANT-BROWN RATTAN

PARTS ENCLOSED:

ITEM	DESCRIPTION	QTY.
(A)	Mounting plate	1
(B)	Mounting Plate Screws	2
(C)	Canopy	1
(D)	Canopy Screw	4
(E)	Pendant	1
(G)	Dome Nut	4
(H)	Allen key	1
(i)	Bulb (not included)	3



IMPORTANT SAFETY INSTRUCTIONS:

1. Use an authorized and certified electrician for consultation and installation. Electrician must be familiar with commercial - type applications of Pendants.
2. It is recommended to use 3 x 40 - Watt maximum Type B standard bulb.
3. To avoid the risk of fire, do not exceed the recommended wattage.
4. The manufacturer and distributor accept no liability for incorrect installation.
5. For indoor use only.
6. Keep away from children.

WARNINGS:

1. Turn - off electricity supply at main circuit panel before installing. Do not connect electricity supply until your ceiling light is fully assembled and installed.
2. To reduce the risk of fire, electrical shock, or personal injury, always turn off the ceiling light and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
3. Deviation from instruction may result in a risk of fire or electric shock. Please read all instructions completely before installation.

TO ASSEMBLE:

1. Carefully unpack the pendant. Do not discard any material till assembly is complete.
2. Place the larger shade upside down on the flat surface.
3. Now keep the smaller shade onto the larger shade and aligning the hole on the studs and tighten the same with dome nuts.
4. Turn OFF power to the Outlet box where the ceiling light will be installed.
5. Determine the Clutch wire length desired by unlocking wire bushes. Then lock the wire bushes after achieving the desired wire length. The Braided wire should be loosen up after slightly unscrewing the strain relief screw and adjust according to the Clutch wire length. Now tighten the strain relief screw.
6. Gently pull wiring down from ceiling junction box and allow to hang
7. Remove the Mounting Plate (A) from the Canopy (C) by unscrewing Top Screw (D)
8. Attach Terminal Mounting Plate (A) to the ceiling Outlet Box.
9. Attach the Ground Wire, Neutral wire & Live wire to respective wires of the Outlet Box.
10. Install the Canopy (C) to Mounting plate (A) and fix it by Canopy Screw (D).
11. Install 3 Type B bulb maximum 40 watt (not included) into the Socket
12. Restore Power to the Outlet box and test ceiling light fixture.

CARE INSTRUCTIONS:

To clean, use a soft dry cloth only. Do not use any chemical or abrasive cleaners.