




# ASSEMBLY INSTRUCTION

## MODEL: WOODEN SIDEBORD

### HARDWARE LIST

|   |                                                                                   |              |                |   |
|---|-----------------------------------------------------------------------------------|--------------|----------------|---|
| A |  | Shelf Holder | Ø7 x 10 x 20mm | 8 |
|---|-----------------------------------------------------------------------------------|--------------|----------------|---|



# INSTRUCTION FOR LEVELER MODEL: WOODEN SIDEBOARD

## ADJUSTING FLOOR LEVELERS



Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

## ADJUST THE FLOOR LEVELERS

**Check for Stability** - Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

**Locate the Levelers** - These are small adjustable feet found at the bottom corners of your furniture.

**Adjust as Needed** - Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.



# INSTRUCTION FOR DOOR HINGE


## Adjust the Hinges (If Necessary)

Once the furniture is level, check the doors. If they appear misaligned or don't close properly:

Make sure that the furniture is level left to right and front to back before attempting to adjust the hinges

**Identify the Hinges** - The hinges have adjustment screws that control movement in different directions.

1. Up and Down Adjustment: To move the cabinet door higher or lower.
2. Left and Right Adjustment: To shift the cabinet door sideways for alignment.
3. Back and Forth Adjustment: To move the cabinet door closer to or farther from the cabinet frame.



## TIPS FOR ADJUSTMENT:

These "adjustments" are not preset and will need to be checked to meet the desired look.

- We recommend the use of a **#2 Phillips Screwdriver**.
- Adjust in **small steps** and check your progress frequently.
- Use a **measuring tape** to ensure the gaps between the top and bottom of the door are even.
- Avoid forcing the door closed if it does not align properly, as this may damage the door.
- If the alignment is still off, make further adjustments as needed.

By following these steps, you can achieve a balanced door alignment.