

Installing your SCHWUNG Pulsar 150

Globe Collection

Pulsar 150

2023



Our goal is to bring energy, warmth and pleasure into your personal space. It's great to be here.

Safety instructions	6
Components and features	7
Assembly instructions	8
Cleaning and maintenance	12
Troubleshooting	13

Safety instructions



We recommend installation by a licensed electrician.

Safety instructions

These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.

1. Turn off electricity at the main circuit breaker panel before beginning installation.
2. This direct wire fixture must be installed by a certified and licensed electrician. The customer should not attempt to install.
3. This fixture has been rated for up to 1 (E) 5W max 230V E12 base bulb. To avoid the risk of fire, do not exceed the recommended wattage.
4. If any special control devices are used with this fixture, follow the instructions to assure full compliance with the N.E.C. requirements.
5. This fixture should only be used with a trailing edge dimmer.
6. Mounting hooks and wall anchors are not included. To select the proper type of mounting hook /wall anchor for your wall/ceiling please contact your local hardware store for assistance. If you have any questions, contact a licensed electrical contractor.

Warnings


- Do not mount or unmount the glass globes if the fixture or light bulbs are hot.
- All wires are connected. Do not remove the ceiling light from its packaging by pulling on the power cord, as a bad connection may result.
- Do not use if the light cable/cord is damaged.
- To reduce the risk of fire, electrical shock or personal injury, always turn off the light fixture and allow it and the globes to cool prior to replacing light bulb.
- When mounting the fixture, always use the cotton gloves included.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.

Components and features

FEATURES

- Hand-crafted in brass
- Mouth-blown glass globes

COMPONENTS



A Mounting plate (1x)
B Top wall plate (1x)
C Globe cap (1x)
D Glass globe (x)
E 5W LED E12 bulb (1x)

Not Included
(recommended for installation):
Wall anchors
Screw
Electric drill

Tools Enclosed:


Pair of cotton gloves
Allen key

Assembly instructions




Make sure you cut off power supply at the main fuse box/circuit breaker before commencing any work.

1




Use the included Allen key to unscrew the small lock screw on the ceiling plate.

2



Remove the wall plate and place the fixture on a soft surface.


3



Place the mounting plate against the wall, mark spots for anchors and drill the holes. Mount the plate to the wall.


NOTE: The position of the mounting plate determines the position of the fixture, please plan carefully to keep the vertical position.

4



Carefully lift the fixture and make all necessary electrical connections.


5



Use the included terminals to connect the wires and place the terminal holder flat in the ceiling plate.


NOTE: We recommended installation by a licensed electrician.

6



Slide the fixture plate into the ceiling plate as in the picture. Make sure no wires are squeezed.


7



Make sure you screw in the lock screw.


NOTE: Risk of the fixture falling off if lock screw not screwed in.

8




Once the fixture is mounted, take the bulb included in the packaging and screw it in.

9




Slide the glass globe over the bulb. Make sure you wear the included cotton gloves.

10




Move the globe slightly down to make sure the opening slides over the bottom clamp.

11




Slide the globe up so that the opening catches the bottom clamp.

12



Slide the globe over the upper clamp till it stops.

13



Restore power and enjoy your Schwung Lamp.

Cleaning and maintenance



Make sure you cut off power supply to the lamp before commencing cleaning operations.

Components	Maintenance	Tools
Brass Frame	Clean every month using a soft cloth, dampened slightly with water. Make sure the frame is dry before switching the lamp back on.	Soft cloth, water
Glass globes	Clean regularly with a soft dry cloth. Clean only the outside of the globe. If especially dirty, use a wet cloth first. Grease can be removed with a gentle glass cleaner.	Soft cloth, Cotton gloves (!)
Light bulbs	Make sure your power supply is off before changing the bulb. Unscrew the globe where bulb needs replacing. Gently remove the bulb by pulling it out and replace with a LED bulb of the same parameters.	LED bulbs, Cotton gloves (!)

NOTE: Please remember, solid brass may tarnish over time. This is a natural process. Make sure you follow our guidelines to preserve the great look of Schwung lighting for years.

Troubleshooting

Problem	Possible Cause	Action
Tarnishing	Oxidation of brass is a natural process. Although it is lacquered, its color may change slightly over time.	No action is necessary apart from regular cleaning. See the Maintenance section.
Globe deformations	Mouth-formed glass globes are beautiful but not perfect. The process leaves a slight deformation at the bottom of the globe.	No action is necessary. All globes undergo a quality check. Should you have any doubts, please send us a photo of the deformed globe and we will act accordingly.

NOTE: Dear client, please be assured our team strives to deliver the highest quality products. The handmade nature of the products offers a unique aesthetic experience and allows for small imperfections, which is inherent to their craft. If solutions offered below are not sufficient, please do not hesitate and contact our customer service.

Having trouble?

We're sorry to hear that.

Our enlightened objects are designed for longevity. Each piece is made by hand to ensure the highest possible quality and a unique aesthetic experience. This means you may encounter small surface imperfections. We like to think of them as whispered greetings from our craftspeople. But should you have any concerns about your product and the previous solutions fail to help, please don't hesitate to email us at info@schwung.design

