



ASSEMBLY INSTRUCTION

Saldana Sectional


Universal assembly of the sectionals



How to disconnect



The prong and the connector must be aligned well.



Lift up the right sectional and pull it out .

