




ASSEMBLY INSTRUCTION

EDISON DINING TABLE



No	Part List	Qty
1	Table Top	1
2	Table Legs	2
3	Center Rail	1
4	Stretcher	1
5	Center Leg	1
Name of Hardware		
A	Bolt M8 X 60	8
B	Bolt M8 X 90	4
C	Washer M8	12
D	Spring Washer M8	12
E	Hex Socket	1


Step: 1




ASSEMBLY INSTRUCTION

EDISON DINING TABLE


Step: 2



Step: 3




Step: 4




ASSEMBLY INSTRUCTION

EDISON DINING TABLE



Adjustable Leveler



FINISH

Adjusting Floor Levelers

Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

Adjust the Floor Levelers

Check for Stability - Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

Locate the Levelers - These are small adjustable feet found at the bottom corners of your furniture.

Adjust as Needed - Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.