

ASSEMBLY INSTRUCTION FOR

MODEL: EDEN 6 DRAWER DRESSER







1



Tipping Hardware


1 SET

Tipping Hardware



★ **REMARK:** There is a tip restraint kit provided on the back of this product please read the direction thoroughly and install immediately

ASSEMBLY INSTRUCTION FOR MODEL: EDEN 6 DRAWER DRESSER



Adjusting Floor Levelers

Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.

Adjust the Floor Levelers

Check for Stability - Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

Locate the Levelers - These are small adjustable feet found at the bottom corners of your furniture.

Adjust as Needed - Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.