




ASSEMBLY INSTRUCTIONS

FIGURE PENDING

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.



HARDWARE LIST			
A		CANOPY	01
B		MOUNTING PLATE	01
C		BODY	01
D		BULB (NOT INCLUDED)	04
E		CHAIN WITH QUICK LINK	01




INSERT THE BULB

ASSEMBLY INSTRUCTIONS


FIGURELLA PENDANT

A




Unlock the canopy screw to remove mounting plate

B



Fix mounting plate



C



Unlock the screw to
adjust chain height
as per requirement

ASSEMBLY INSTRUCTIONS

FIGURELLA PENDANT



FINISHED

ASSEMBLY INSTRUCTIONS

FIORELLA PENDANT

WIRING CONNECTIONS

1. Shut down the power at the breaker panel.
2. Connect wires:
 - Ground wire: Connect fixture ground wire (green) to supply ground wire
 - Neutral wire: Connect fixture neutral wire (white) to supply neutral wire
 - Hot wire: Connect fixture hot wire (black) to supply hot wire
3. Make sure all connections are tight, then carefully tuck into the junction box

IMPORTANT SAFETY INSTRUCTIONS

Use an authorized and certified electrician for consultation and installation. Electricians must be familiar with commercial-type applications of chandeliers.

It is recommended to use 4 x 25 watt maximum type B standard Bulb

WARNINGS

When unpacking, be careful not to pull wires, as a bad connection may result. Do not connect electricity until your fixture is fully assembled. Do not touch or look directly at the Bulb when the fixture is illuminated. Keep flammable materials away from lit Bulb.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.

STRANGULATION HAZARD

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds.
Keep out of reach of children under 3 years of age.