

ASSEMBLY INSTRUCTIONS FOR LYLE MEDIA CONSOLE

PART LIST



NO.	DESCRIPTION	QTY
A	Desktop	1pc
B	Table Leg	2pcs

HARDWARE LIST

NO.	PICTURE	DESCRPTON	SPEC.	QTY
1		Allen Bolt	M8 x 25mm	16pcs
2		Flat Washer	M8 x 18 x 1mm	16pcs
3		Lock Washer	M8 x 13 x 2mm	16pcs
4		Allen Key	M5	1pc

Assembly Steps

- Step 1** Note: The floor must be covered with protective material so that the table top does not touch the floor directly



Adjusting Floor Levelers

Your furniture has been expertly crafted and pre-adjusted by professionals. However, slight shifts can occur during transportation. If you notice that the doors are not perfectly aligned or the furniture wobbles, a quick adjustment can help ensure stability and a seamless look.


Adjust the Floor Levelers

Check for Stability – Place the furniture in its final position on a level surface. If it wobbles or doesn't sit evenly, the floor levelers need adjusting.

Locate the Levelers – These are small adjustable feet found at the bottom corners of your furniture.

Adjust as Needed – Using your hand or a wrench, turn the levelers clockwise to raise or counterclockwise to lower the furniture. Make small adjustments and check stability after each turn.

Examples



If you need further adjustments, repeat the process in small increments.