



















# ASSEMBLY INSTRUCTION

DELAY COFFEE TABLE			
Part No.	Product Image	Description	Qty.
1.		Wood Top	1
2.		Wood Leg	1
3.		Iron Plate	4
4.		Iron Plate	4
5.		Flat Bolt (8mm x 30mm)	16
6.		Bolt (8mm x 20mm)	16
7.		Washer	16
8.		AllenKey	1



Note-  
Level Adjustment-In case the item is not leveled ,you can use the levelers  
to adjust.