
ASSEMBLY INSTRUCTION FOR

Lawndale 3PC LAF Sectional

Universal assembly of the sectionals

How to disconnect



The prong and the connector must be aligned well.

