


ASSEMBLY INSTRUCTIONS



LEROY OUTDOOR SOFA 96" - CUSHION COVER

A. Base Cover Cushion


① Top




② Bottom



③




④ Close





B. Back Cover Cushion


① Top



② Bottom



③



④ Close

