



ASSEMBLY INSTRUCTIONS SONOMA OUTDOOR CHAIR - CUSHION COVER

① TOP




② BOTTOM




OPEN

③




CLOSE

④




PILLOW COVER


①



②



③



④

